COCOON™ FOUNDATION ASSEMBLY INSTRUCTIONS

Contents

• 2 Side Rails (both side rails are identical and may

• 2 End Rails (both end rails are identical and may be used on either side of the foundation)

- 1 Center Support Rail (unless King/Cal King 2 each)
- 4 Fast Loc Pins (all 4 pins shipped installed in the side/end rails)
- 2 Support Slat Packs (6 slats per pack)
- 1 Instruction Sheet



Step 1

Align Fast Loc blocks in each of the four corners

Step 2

Insert Fast Loc Pins into each of the 4 Fast Loc Blocks, pushing firmly to ensure proper alignment

Step 3

Line up each end of the Center Rail with the corresponding "Tapered Slide Connector" and firmly push down into place, making sure the "Up Arrow" faces upward.

Step 4

Start one end of each Support Slat Pack against the head/foot board, with the hook side facing down to firmly catch the loop material on each side rail clear. Unroll the Slat Packs towards the center fully extending them.

To see an instructional video, please visit www.cocoonbysealy.com.







